

wraps your house in warmth

ECCO STOVE OUTSIDE AIR KIT

Outside air connection may be made directly onto Ecco Stove® range with the addition of an Outside Air Kit (air box).

The Outside Air Kit consists of:-

- Complete air box assembly
- 1 metre length 60mm air tube
- Insulation 600mm chopped to air tube
- 2 clamps
- Brown outside air box and cutable tube

Assembly

1. Site the stove base section in place
2. Fit the base trim – (not applicable with trimless models)
3. Clip air box over back of stoves body



Outside Air Kit Instructions | current as of April 2016 | Version 1

All information supplied by **Ecco Stove®** is a trade mark of Landy Vent UK Limited
copyright©EccoStove2015

Ecco Stove | Foster House | 2 Redditch Road, Studley, B80 7AX, United Kingdom

T | +44 (0)1527 857 814 E | sales@eccostove.com W | www.eccostove.com
Patent pending USA, Canada, Europe & Russia | UK Patent nos: 2467433 & 2498883

wraps your house in warmth

4. Fit stove sides and back panel to firmly fix air box into place.



5. Connect the 1 metre air tube onto the spigot tail (over the gasket tape) and tighten the clamp.



6. Fix the grille pre attached to the air tubes opposite end onto the cutable wall tube
7. Fix the brown cover outside

Outside Air Kit Instructions | current as of April 2016 | Version 1

All information supplied by **Ecco Stove®** is a trade mark of Landy Vent UK Limited
copyright©EccoStove2015

Ecco Stove | Foster House | 2 Redditch Road, Studley, B80 7AX, United Kingdom

T | +44 (0)1527 857 814 E | sales@eccostove.com W | www.eccostove.com
Patent pending USA, Canada, Europe & Russia | UK Patent nos: 2467433 & 2498883